



The Cat.6 10-GBits-connector

No special tools required, high-performance connection

1. Remove about 20 mm of the plastic sheath, remove the shield foil of the wire pairs, fold braided shield backwards and wrap it around the 5 mm the shield foil
2. Insert the wire pairs (see PIN assignment) in the lower wire guides of the loader
3. Insert the remaining wire pairs (see PIN assignment) in the upper wire guides of the loader and close the cable strain release clamp
4. Cut the wire ends flush
5. Make sure that the loader is correctly aligned with the lower housing and press until the housing is closed

Open the plug: Unclip the loader using a small, flat-bladed screwdriver (I) and separate the two housing parts (II).

Anschlussbelegung / PIN assignments			
PIN Nr. / No.	T568A	T568B	INDUSTRIAL
1	WH-GN	WH-OG	YE
2	GN	OG	OG
3	WH-OG	WH-GN	WH
4	BU	BU	-
5	WH-BU	WH-BU	-
6	OG	GN	BU
7	WH-BN	WH-BN	-
8	BN	BN	-