

Napájecí adaptér pro notebooky, 230V - 19V/6A, 120W

Katalogové číslo: 60.00.2025

Napájecí zdroj DC 19V minimálně 6A se souosým napájecím konektorem 5,5 x 2,5mm.

Použitelné pro zařízení:

COMPAQ	Armada 110 series, Armada E500, Armada E700, Armada M300, Armada M700, Armada V300, Evo N110, Evo N150, Evo N200, Evo N400c, Evo N410c, Evo N600c, Evo N610c, Evo N800c, Evo N800v, Presario 900, Presario 2800 series, Presario 2800T, Presario 2805US, Armada 4100series, Armada 4200series, Presario 300, Presario 900, Presario 1500, Presario 2800 series, A4 ACER AcerNote 367, AcerNote 390series, Extensa 360series, Extensa 390series, Extensa 900, Extensa ESS3-391T Compaq Armada 2924 series, Evo N105, Evo N115, Evo N160, Evo N180, Evo 18XL, Evo 2700 series, Evo 2700T, Evo 800XL, Presario 700series, Presario 800, Presario 800XL, Presario 1000series, Presario 1200series, Presario 710, Presario 720, Presario 12XL, Presario 1400, Presario 14XL, Presario 1600, Presario 1700, Presario 17XL, Presario 1800
SAMSUNG	Sens 900, Sens 950, Sens V10, Sens 690
ACER	AcerNote 350series, AcerNote 370series, AcerNote 850C, AcerNote Light 350, AcerNote Light 360, AcerNote Light 370, AcerNote Light 380series, P100 Extensa 355, Extensa 500, Extensa 501, Extensa 502, Extensa 503, Extensa 600, Extensa 610series, Extensa 505DX, Extensa 506DX, Travelmate 505, Travelmate 506, Travelmate 507, Travelmate 524series
AST	Ascentia 800N series, Ascentia 810N, Ascentia 910N, Ascentia 925N, Ascentia 950N, Ascentia P series
DELL	Latitude 433, Latitude 450, Latitude 475, Latitude LX, Latitude LX4100 series, Inapiron 3000, Inapiron 3200, Inapiron 3500series, Inapiron 7000series, Inspiron 1100 series, Inspiron 5100 series, Latitude LX450, Latitude XP series, Latitude C, Latitude CP, Latitude CS, Latitude Xpi series Inspiron 2500, Inspiron 3700, Inspiron 3800, Inapiron 4000, Inapiron 5000, Inapiron 5000e, Inapiron 7500, Inapiron 8000, Inapiron 8100, Inapiron 8200 series A10
SHARP	PC 3000 series, PC 8000 series, PC 9000 series, PC S400
TWINHEAD	SlimNote 5100series, SlimNote 550S, SlimNote 575, SlimNote 600D, SlimNote 6100series, SlimNote 100series, SlimNote 875series, SlimNote 890series, SlimNote 9 series, SlimNote 9100, SlimNote 910CV, SlimNote 9133series, SlimNote 9150TZ, SlimNote 9166TZ, SlimNote VX, SlimNote VXE, SlimNote VXE3, SlimNote P88, SlimNote P88TE A5
HP	Omnibook XE, Omnibook XE2, Omnibook XE3series, Omnibook ZT, Omnibook ZE, Omnibook XZ, Omnibook XT series, Omnibook 500, Omnibook 900, Omnibook 4100, Omnibook 4150, Omnibook 6000 series, Omnibook 2100, Omnibook 3000, Omnibook 3100 series, Omnibook 4000, Omnibook 7000, Omnibook 7100, Omnibook 7150 series Pavilion ZE, Pavilion XT, Pavilion ZFseries, Pavilion N3000series, Pavilion N3100, Pavilion N3150, Pavilion N3250, Pavilion N3270(N3290/5), Pavilion N3310, Pavilion N3330, Pavilion N3350, Pavilion N3370, Pavilion N3390, Pavilion N3410, Pavilion N5000series, Pavilion N5100, Pavilion N5125, Pavilion N5130, Pavilion N5150, Pavilion N5170(N5190/5), Pavilion N5200, Pavilion N5210, Pavilion N5270(N5290/5), Pavilion N5300, Pavilion N5340, Pavilion N5380, Pavilion N5350(N5390/5), Pavilion N5400series, Pavilion N5511L, Pavilion N5584, Pavilion ZT1100, Pavilion XH series, Pavilion XZ185, Pavilion XZ275, Pavilion XZ295, Pavilion XZ355, Pavilion XF328, Pavilion ze4100, Pavilion ze1000 series
IBM	Thinkpad i1400, Thinkpad i1442, Thinkpad i1460, Thinkpad i1480, Thinkpad i1482, Thinkpad i1500, Thinkpad i1522, Thinkpad i1700, Thinkpad i1720 series, Thinkpad T40, Thinkpad 355series, Thinkpad 360series, Thinkpad 370, Thinkpad 380series, Thinkpad 450C, Thinkpad 700series, Thinkpad 720series, Thinkpad 750series, Thinkpad 755series, Thinkpad 760series, Thinkpad 765series, Thinkpad 790
MICRON	TransPort Trek2 233, TransPort Trek2 266, TransPort Trek2 300 DVD
NEC	Versa 500, Versa 550D, Versa 2400series, Versa 2500series, Versa 5000, Versa 5060series, Versa 5080series, Ready 440T Sharp PC 3010 series, PC 3020 series, PC 3050 series, PC 3060 series, PC 3150 series, Ready 220T, Ready 230T, Ready 330T, Ready 340T, Ready 360T A6
TOSHIBA	Satellite 1600, Satellite 1700, Satellite 1900, Satellite 3000, Satellite 1715XCDS series, Satellite 1905-S301, Satellite 1955-S801, Satellite 2430 series, Satellite 2435 series
SONY	VAIO PCG-700, VAIO 800, VAIO 900, VAIO 705, VAIO 707, VAIO 731, VAIO 717, VAIO 719, VAIO 729, VAIO 735, VAIO 748, VAIO 808, VAIO 812, VAIO 818, VAIO 838, VAIO PCG-F, VAIO PCG-R505, VAIO PCG-XG, VAIO PCG-R505D, VAIO R505DX, VAIO GRX series A8
APPLE	Apple PowerBook M8758, PowerBook M8760, PowerBook M8793, PowerBook M8858, PowerBook M8859, PowerBook M9009, PowerBook M9018 series A11 Apple PowerBook G3, PowerBook 1400, PowerBook 2400, PowerBook 3400 series, iBook M2453 A12