

Redukce napájení z konektoru 5,5 x 2,5mm (C6)

Katalogové číslo: 60.00.2806



Použitelné pro zařízení:

ACER	<p>AcerNote LifeNote 373, AcerNote Light 350, AcerNote Light 360, AcerNote Light 370, AcerNote Light 371, AcerNote Light 372, AcerNote Light 373, AcerNote Light 374, AcerNote Light 380, AcerNote 330T, AcerNote 350, AcerNote 367, AcerNote 3680, AcerNote 370, AcerNote 380, AcerNote 382, AcerNote 850C, Alpha 550, Alpha 550LC, Alpha 550LV, Alpha 550XV, Alpha 551, Alpha 551VX, Aspire AS5552, Aspire AS5552G, Aspire One, Aspire One A110, Aspire One A110-Ab, Aspire One A110-Ac, Aspire One A110-AGb, Aspire One A110-AGc, Aspire One A110-Bb, Aspire One A110-Bc, Aspire One A110-BGb, Aspire one A110L, Aspire one A110L blau, Aspire one A110X, Aspire One A110X Black Edition, Aspire One A110-1041, Aspire One A110-1137, Aspire One A110-1283, Aspire One A110-1295, Aspire One A110-1588, Aspire One A110-1626, Aspire One A110-1662, Aspire One A110-1691, Aspire One A110-1698, Aspire One A110-1722, Aspire One A110-1812, Aspire One A110-1831, Aspire One A110-1834, Aspire One A110-1948, Aspire One A110-1982, Aspire One A110-1995, Aspire One A150, Aspire One A150-Ab, Aspire One A150-Ac, Aspire One A150-Ap, Aspire One A150-Aw, Aspire One A150-Bb, Aspire One A150-Bb1, Aspire One A150-Bc, Aspire One A150-BGb, Aspire One A150-BGc, Aspire One A150-BGp, Aspire One A150-BGw, Aspire One A150-Bk, Aspire One A150-Bk1, Aspire One A150-Bp, Aspire One A150-Bw, Aspire One A150-Bw1, Aspire One A150L, Aspire one A150L blau, Aspire one A150L weiss, Aspire One A150X, Aspire one A150X blau, Aspire one A150X weiss, Aspire One A150-1001, Aspire One A150-1006, Aspire One A150-1029, Aspire One A150-1035, Aspire One A150-1049, Aspire One A150-1068, Aspire One A150-1083, Aspire One A150-1126, Aspire One A150-1140, Aspire One A150-1141, Aspire One A150-1172, Aspire One A150-1178, Aspire One A150-1249, Aspire One A150-1316, Aspire One A150-1329, Aspire One A150-1348, Aspire One A150-1359, Aspire One A150-1382, Aspire One A150-1400, Aspire One A150-1405, Aspire One A150-1435, Aspire One A150-1444, Aspire One A150-1447, Aspire One A150-1483, Aspire One A150-1485, Aspire One A150-1493, Aspire One A150-1504, Aspire One A150-1505, Aspire One A150-1532, Aspire One A150-1553, Aspire One A150-1555, Aspire One A150-1570, Aspire One A150-1622, Aspire One A150-1635, Aspire One A150-1649, Aspire One A150-1672, Aspire One A150-1679, Aspire One A150-1690, Aspire One A150-1706, Aspire One A150-1742, Aspire One A150-1777, Aspire One A150-1784, Aspire One A150-1786, Aspire One A150-1798, Aspire One A150-1840, Aspire One A150-1864, Aspire One A150-1887, Aspire One A150-1890, Aspire One A150-1905, Aspire One A150-1949, Aspire One A150-1983, Aspire One A150-1987, Aspire One D1X0, Aspire One D150, Aspire One D150-1B, Aspire One D150-1Bk, Aspire One D150-1Br, Aspire One D150-1Bw, Aspire One D150-1044, Aspire One D150-1125, Aspire One D150-1165, Aspire One D150-1186, Aspire One D150-1197, Aspire One D150-1240, Aspire One D150-1322, Aspire One D150-1462, Aspire One D150-1577, Aspire One D150-1587, Aspire One D150-1606, Aspire One D150-1647, Aspire One D150-1669, Aspire One D150-1739, Aspire One D150-1860, Aspire One D150-1920, Aspire One D2X0, Aspire One D250, Aspire One D250-1Bb, Aspire One D250-1Br, Aspire One D250-1Bw, Aspire One D250-1026, Aspire One D250-1042, Aspire One D250-1116, Aspire One D250-1151, Aspire One D250-1165, Aspire One D250-1185, Aspire One D250-1289, Aspire One D250-1326, Aspire One D250-1610, Aspire One D250-1924, Aspire One D250-1990, Aspire One D255, Aspire One D255E, Aspire One D257, Aspire One D260, Aspire One Happy, Aspire One HAPPY2, Aspire One Pro 531, Aspire One ZG5, Aspire One 521, Aspire One 522, Aspire One 531, Aspire One 532, Aspire One 532h, Aspire One 532h-B123, Aspire One 532h-B123F, Aspire One 532h-CBW123G, Aspire One 532h-CPK11, Aspire One 532h-CPR11, Aspire One 532h-CPW11, Aspire One 532h-R123, Aspire One 532h-W123, Aspire One 532h-W123F, Aspire One 532h-2Bb, Aspire One 532h-2Bs, Aspire One 532h-2Db, Aspire One 532h-2Dr, Aspire One 532h-2Ds, Aspire One 532h-2067, Aspire One 532h-2206, Aspire One 532h-2223, Aspire One 532h-2242, Aspire One 532h-2268, Aspire One 532h-2288, Aspire One 532h-2298, Aspire One 532h-2309, Aspire One 532h-2326, Aspire One 532h-2333, Aspire One 532h-2382, Aspire One 532h-2406, Aspire One 532h-2527, Aspire One 532h-2575, Aspire One 532h-2588, Aspire One 532h-2594, Aspire One 532h-2622, Aspire One 532h-2630, Aspire One 532h-2676, Aspire One 532h-2727, Aspire One 532h-2730, Aspire One 532h-2742, Aspire One 532h-2789, Aspire One 532h-2806, Aspire One 532h-2807, Aspire One 532h-2825, Aspire One 532h-2938, Aspire One 532h-2942, Aspire One 532h-2962, Aspire One 532h-2964, Aspire One 532h-2997, Aspire One 533, Aspire One 533- 23571, Aspire One 721, Aspire One 721-3574, Aspire One 722, Aspire One 753, Aspire One 532h-CBK123G, Aspire S3-951, Aspire Timeline 1810T, Aspire Timeline 3810T, Aspire Timeline 3820T, Aspire Timeline 4810T, Aspire Timeline 4820T, Aspire Timeline 5810T, Aspire Timeline 5820T, Aspire TimelineX 3830TG, Aspire TimelineX 4820TG, Aspire TimelineX 4830TG, Aspire TimelineX 5830T, Aspire 1200, Aspire 1200X, Aspire 1200XV, Aspire 1202, Aspire 1202X, Aspire 1203X, Aspire 1203XC, Aspire 1203XV, Aspire 1300, Aspire 1350, Aspire 1410, Aspire 1414WLCi, Aspire 1420P, Aspire 1430, Aspire 1450, Aspire 1551, Aspire 1640, Aspire 1640Z, Aspire 1642WLMi, Aspire 1650, Aspire 1650Z, Aspire 1680, Aspire 1690, Aspire 1690-II, Aspire 1810T, Aspire 1810TZ, Aspire 1820PT, Aspire 1825PTZ, Aspire 1830, Aspire 1830T, Aspire 2000, Aspire 2010, Aspire 2012WLCi, Aspire 2020, Aspire 2420, Aspire 2920, Aspire 2930, Aspire 3000, Aspire 3010, Aspire 3020, Aspire</p>
-------------	---

3030, Aspire 3040, Aspire 3050, Aspire 3100, Aspire 3200, Aspire 3410, Aspire 3500, Aspire 3510, Aspire 3600, Aspire 3610, Aspire 3620, Aspire 3628AWXci, Aspire 3630, Aspire 3640, Aspire 3650, Aspire 3660, Aspire 3670, Aspire 3680, Aspire 3690, Aspire 3810 Timeline, Aspire 3810T, Aspire 3810TZ-4880, Aspire 3810T-354G32n, Aspire 3810T-6415, Aspire 3810T-944G32n, Aspire 3820T, Aspire 3820TG, Aspire 3935, Aspire 3935-CF61, Aspire 3935-CF61F, Aspire 3935-6504, Aspire 3935-744G25Mn, Aspire 3935-864G32Mn, Aspire 4220, Aspire 4220G, Aspire 4230, Aspire 4232, Aspire 4251, Aspire 4252, Aspire 4310, Aspire 4315, Aspire 4320, Aspire 4320G, Aspire 4330, Aspire 4333, Aspire 4520, Aspire 4520G, Aspire 4530, Aspire 4535, Aspire 4540, Aspire 4551, Aspire 4552, Aspire 4553, Aspire 4710, Aspire 4710G, Aspire 4710Z, Aspire 4710ZG, Aspire 4720, Aspire 4720G, Aspire 4730Z, Aspire 4730ZG, Aspire 4732Z, Aspire 4733Z, Aspire 4736Z, Aspire 4738, Aspire 4738Z, Aspire 4739, Aspire 4739Z, Aspire 4741, Aspire 4741G, Aspire 4743, Aspire 4743Z, Aspire 4745, Aspire 4745Z, Aspire 4750, Aspire 4750G, Aspire 4752, Aspire 4752Z, Aspire 4755G, Aspire 4810T, Aspire 4810TZ, Aspire 4820T, Aspire 4820TG, Aspire 4920, Aspire 4920G, Aspire 4930, Aspire 4930G, Aspire 5000, Aspire 5010, Aspire 5020, Aspire 5030, Aspire 5040, Aspire 5050, Aspire 5100, Aspire 5110, Aspire 5230, Aspire 5235, Aspire 5236, Aspire 5250, Aspire 5251, Aspire 5252, Aspire 5253, Aspire 5310, Aspire 5315, Aspire 5320, Aspire 5330, Aspire 5332, Aspire 5333, Aspire 5334, Aspire 5335, Aspire 5336, Aspire 5349, Aspire 5350, Aspire 5500, Aspire 5500Z, Aspire 5510, Aspire 5515, Aspire 5516, Aspire 5517, Aspire 5520, Aspire 5520G, Aspire 5530, Aspire 5530G, Aspire 5532, Aspire 5534, Aspire 5535, Aspire 5535-704G32Mn, Aspire 5536, Aspire 5536G, Aspire 5538, Aspire 5540, Aspire 5542, Aspire 5542G, Aspire 5550, Aspire 5551, Aspire 5551G, Aspire 5552, Aspire 5552G, Aspire 5553, Aspire 5553G, Aspire 5560, Aspire 5560G, Aspire 5570, Aspire 5570Z, Aspire 5580, Aspire 5590, Aspire 5600, Aspire 5610, Aspire 5610Z, Aspire 5620, Aspire 5630, Aspire 5650, Aspire 5670, Aspire 5672, Aspire 5680, Aspire 5690, Aspire 5710, Aspire 5710G, Aspire 5710Z, Aspire 5710ZG, Aspire 5715Z, Aspire 5720, Aspire 5720G, Aspire 5720Z, Aspire 5720ZG, Aspire 5730Z, Aspire 5730ZG, Aspire 5732Z, Aspire 5733, Aspire 5733Z, Aspire 5734Z, Aspire 5734Z, Aspire 5735, Aspire 5735Z, Aspire 5736Z, Aspire 5738, Aspire 5738DG, Aspire 5738G, Aspire 5738PG, Aspire 5738Z, Aspire 5738ZG, Aspire 5739G, Aspire 5740, Aspire 5740DG, Aspire 5740G, Aspire 5741, Aspire 5741G, Aspire 5741Z, Aspire 5742, Aspire 5742G, Aspire 5742Z, Aspire 5745, Aspire 5745G, Aspire 5745PG, Aspire 5749, Aspire 5749Z, Aspire 5750, Aspire 5750G, Aspire 5750G-2312G50, Aspire 5750Z, Aspire 5755, Aspire 5755G, Aspire 5810T, Aspire 5810TZ, Aspire 5820T, Aspire 5820TG, Aspire 5910G, Aspire 5920, Aspire 5920G, Aspire 5930, Aspire 5930G, Aspire 5935, Aspire 5943G, Aspire 5949, Aspire 6530, Aspire 6530G, Aspire 6920, Aspire 6920G, Aspire 6930, Aspire 6930G, Aspire 6935, Aspire 6935G, Aspire 7000, Aspire 7100, Aspire 7110, Aspire 7220, Aspire 7230, Aspire 7250, Aspire 7330, Aspire 7520, Aspire 7520G, Aspire 7530, Aspire 7530G, Aspire 7535, Aspire 7540, Aspire 7540G, Aspire 7551, Aspire 7551G, Aspire 7560, Aspire 7560G, Aspire 7715Z, Aspire 7720, Aspire 7720G, Aspire 7720Z, Aspire 7730, Aspire 7730G, Aspire 7730Z, Aspire 7730ZG, Aspire 7735, Aspire 7735Z, Aspire 7736, Aspire 7736Z, Aspire 7738G, Aspire 7739, Aspire 7739G, Aspire 7739Z, Aspire 7740, Aspire 7740G, Aspire 7741, Aspire 7741G, Aspire 7741Z, Aspire 7741ZG, Aspire 7745, Aspire 7745G, Aspire 7745Z, Aspire 7750, Aspire 7750Z, Aspire 8530, Aspire 8540, Aspire 8540, Aspire 8540G, Aspire 8730, Aspire 8730G, Aspire 8735, Aspire 8735G, Aspire 8735ZG, Aspire 8920G, Aspire 8920G-6A4G32Bn, Aspire 8930G, Aspire 910, Aspire 9100, Aspire 9110, Aspire 9120, Aspire 9300, Aspire 9302, Aspire 9400, Aspire 9410, Aspire 9410Z, Aspire 9412WSMi, Aspire 9420, Aspire 9500, Aspire 9510, Aspire 9520, Extensa 355, Extensa 360, Extensa 390, Extensa 391, Extensa 391C, Extensa 391T, Extensa 392, Extensa 392C, Extensa 392T, Extensa 393, Extensa 393C, Extensa 393T, Extensa 394, Extensa 394T, Extensa 395, Extensa 395T, Extensa 4120, Extensa 4220, Extensa 4230, Extensa 4420, Extensa 4620, Extensa 4620Z, Extensa 4630, Extensa 4630Z, Extensa 500, Extensa 501, Extensa 502, Extensa 503, Extensa 505, Extensa 512, Extensa 513, Extensa 514, Extensa 515, Extensa 516, Extensa 517, Extensa 5220, Extensa 5230, Extensa 5230E, Extensa 5235, Extensa 5420, Extensa 5420G, Extensa 5430, Extensa 550, Extensa 555, Extensa 560, Extensa 5620, Extensa 5620G, Extensa 5620Z, Extensa 5630, Extensa 5630G, Extensa 5630Z, Extensa 5635, Extensa 5635Z, Extensa 565, Extensa 570, Extensa 600, Extensa 610, Extensa 616, Extensa 620, Extensa 690, Extensa 700, Extensa 710, Extensa 711, Extensa 712, Extensa 7220, Extensa 7620, Extensa 7620G, Extensa 7620Z, Extensa 7630, Extensa 7630G, Extensa 900, Ferrari FR1000, Ferrari FR1100, Ferrari FR5000, Ferrari One 200, Ferrari 1000, Ferrari 1100, Ferrari 3000, Ferrari 3200, Ferrari 3400, Ferrari 4000, Ferrari 5000, ICONIA TAB W500, ICONIA TAB W500P, TravelMate C100, TravelMate C110, TravelMate C111Ti, TravelMate C200, TravelMate C204Tmi, TravelMate C210, TravelMate C300, TravelMate C300Xci, TravelMate C310, TravelMate K-550, TravelMate Timeline 8371, TravelMate Timeline 8471, TravelMate Timeline 8571, TravelMate 200, TravelMate 210, TravelMate 210T, TravelMate 210TER, TravelMate 212T, TravelMate 212TE, TravelMate 212TXV, TravelMate 213T, TravelMate 213TXV, TravelMate 220, TravelMate 223X, TravelMate 223XC, TravelMate 225X, TravelMate 225XC, TravelMate 225XV-Pro, TravelMate 230, TravelMate 2300, TravelMate 2301, TravelMate 2302, TravelMate 2303, TravelMate 2310, TravelMate 233XC, TravelMate 2350, TravelMate 2352, TravelMate 2353, TravelMate 240, TravelMate 2400, TravelMate 2410, TravelMate 2420, TravelMate 2430, TravelMate 2440, TravelMate 2450, TravelMate 2460, TravelMate 2470, TravelMate 2480, TravelMate 2490, TravelMate 260, TravelMate 270, TravelMate 270XV, TravelMate 280, TravelMate 290, TravelMate 290ATI, TravelMate 290E, TravelMate 292LMi, TravelMate 3000, TravelMate 3010, TravelMate 3020, TravelMate 3030, TravelMate 3040, TravelMate 310, TravelMate 320, TravelMate 3200, TravelMate 3210, TravelMate 3220, TravelMate 3230, TravelMate 3240, TravelMate 3250, TravelMate 3260, TravelMate 3270, TravelMate 3273WXMmi, TravelMate 3280, TravelMate 3290, TravelMate 330, TravelMate 330T, TravelMate 3300, TravelMate 340, TravelMate 340T, TravelMate 341TV, TravelMate 342T, TravelMate 343TV, TravelMate 350, TravelMate 3500, TravelMate 351TEV, TravelMate 360, TravelMate 365, TravelMate 370, TravelMate 380, TravelMate 3900, TravelMate 4000, TravelMate 4000M, TravelMate 4001, TravelMate 4001LMi, TravelMate 4002, TravelMate 4010, TravelMate 4020, TravelMate 4050, TravelMate 4051, TravelMate 4052, TravelMate 4053, TravelMate 4060, TravelMate 4070, TravelMate 4080, TravelMate 4100, TravelMate 4100-II, TravelMate 4150, TravelMate 420, TravelMate 4200, TravelMate 4200WLMmi, TravelMate 4202, TravelMate 4202WLMmi, TravelMate 4210, TravelMate 4220, TravelMate 4230, TravelMate 4260, TravelMate 4270, TravelMate 4280, TravelMate 430, TravelMate 4310, TravelMate 4320, TravelMate 4330, TravelMate 4400, TravelMate 4500, TravelMate 4520, TravelMate 4600, TravelMate 4600-II, TravelMate 4650, TravelMate 4670, TravelMate 4720, TravelMate 4730, TravelMate 4730G, TravelMate 4740, TravelMate 4740Z, TravelMate 4750, TravelMate 505, TravelMate 506, TravelMate 506DX, TravelMate 507, TravelMate 508, TravelMate 510, TravelMate

	5100, TravelMate 5110, TravelMate 514TVX, Travelmate 520, Travelmate 520iT, Travelmate 521, TravelMate 521T, Travelmate 521TE, Travelmate 521TEV, Travelmate 521TXV, TravelMate 5210, Travelmate 522, TravelMate 5220, TravelMate 5220G, TravelMate 5230, Travelmate 524, Travelmate 524TE, Travelmate 524TXV, Travelmate 525, Travelmate 525TX, Travelmate 525TXV, Travelmate 527, Travelmate 527TXV, Travelmate 529, Travelmate 529ATXV, Travelmate 529TXV, Travelmate 530, TravelMate 5310, TravelMate 5320, TravelMate 5330, TravelMate 5340, TravelMate 5400M, TravelMate 5440, TravelMate 550, TravelMate 5510, TravelMate 5520, TravelMate 5520G, TravelMate 5530, TravelMate 5530G, TravelMate 5542, TravelMate 5600, TravelMate 5610, TravelMate 5620, TravelMate 5672WLMi, TravelMate 5710, TravelMate 5710G, TravelMate 5720, TravelMate 5720G, TravelMate 5730, TravelMate 5730G, TravelMate 5730-663G32Mn, TravelMate 5740, TravelMate 5740G, TravelMate 5742, TravelMate 5742Z, TravelMate 5744, TravelMate 5760, TravelMate 600, TravelMate 6000, TravelMate 610, TravelMate 620, TravelMate 6231, TravelMate 6291, TravelMate 6292, TravelMate 6293, TravelMate 630, TravelMate 6410, TravelMate 6460, TravelMate 6492, TravelMate 6493, TravelMate 650, TravelMate 6500, TravelMate 6592, TravelMate 6592G, TravelMate 6593, TravelMate 6593G, TravelMate 6594, TravelMate 6594G, TravelMate 660, TravelMate 662LVi, TravelMate 710, TravelMate 720, TravelMate 7220, TravelMate 7220G, TravelMate 7230, TravelMate 730, TravelMate 7320, TravelMate 7340, TravelMate 740, TravelMate 7510, TravelMate 7520, TravelMate 7520G, TravelMate 7530, TravelMate 7530G, TravelMate 7720, TravelMate 7720G, TravelMate 7730, TravelMate 7730G, TravelMate 7740, TravelMate 7750, TravelMate 7750G, TravelMate 800, TravelMate 8000, TravelMate 8100, TravelMate 8100A, TravelMate 8132, TravelMate 8172, TravelMate 8172T, TravelMate 8172Z, TravelMate 8200, TravelMate 8204, TravelMate 8210, TravelMate 8371, TravelMate 8372, TravelMate 8372G, TravelMate 8372T, TravelMate 8471, TravelMate 8472, TravelMate 8472G, TravelMate 8571, TravelMate 8572, TravelMate 8572G, TravelMate 8572T
DELL	Inspiron Mini 10, Inspiron Mini 10 (1010), Inspiron Mini 10 (1012), Inspiron Mini 10v, Inspiron mini 1012, Inspiron mini 1018, Inspiron Mini 12, Inspiron Mini 9, Inspiron 1010, Inspiron 1010n - PP19S, Inspiron 1011, Inspiron 1011n - PP19S, Inspiron 1210, Inspiron 1210n-PP40S, Inspiron 910, Vostro A90, Vostro A90n-PP39S
EMACHINES	D442, D525, D528, D620, E440, E442, E520, E525, E527, E528, E620, E625, E627, E720, E725
FUJITSU / SIEMENS	Amilo A1650, Amilo A1655g, Amilo A1667EX, Amilo A1667g, Amilo A3667G, Amilo D5100, Amilo D5500, Amilo D6100, Amilo D6500, Amilo D7100, Amilo D7500, LifeBook 30N3
HP / COMPAQ	Presario 300, Presario 305, Presario 306